




Ocea Pro Drill-Free Mount - Installation Manual






1 Check the Items

Upon receiving your order, open the crate and inspect the contents. **Damages must be reported within 24 hours.**

2 Remove the Aluminum Frame

Using an allen key, remove the aluminum frame attached to the TV.



4 Mark the Holes

Place your TV wall box against the wall and mark the holes where your hook pads will be placed.


5 Attach the Pads

Clean the wall by gently wiping isopropyl rubbing alcohol on it, making sure there is no dust. Peel the protective sticker at the back of the pads then stick them onto the wall with the hooks facing in opposite directions. The placement should match where the TV corners will be placed.

6 Remove the Compartment Cover


Use a screwdriver to remove the compartment cover located at the back of the TV.

Ocea Pro Drill-Free Mount - Installation Manual




7 Plug the Power Cord

Insert the power cord through the opening of the compartment cover. Then plug it to the power input port located at the back of the TV.




8 Connect the Audio Cords

Insert one end of the stripped audio cord into the red clip and insert the other end of the cord into the black clip. Then do the same for the other stripped audio cord.




9 Cover the Compartment

Re-attach the compartment cover. Tighten the surrounding screws to make sure that they don't fall during the rest of the installation process.




10 Re-Attach The TV Wall Box And The Frame

Slide the TV back into its TV wall box. Then place the aluminum frame around the TV and tighten its allen screws back in place.




11 Hang the TV to the Wall

Lift the TV and hang it to the four hooks you attached on the wall.




12 Turn on Ocea Pro TV

You can either turn your Ocea Pro TV on by simply touching the power icon on the screen or by clicking the power button on your Evervue remote.



13 Control your TV

On the Zapp remote included in the package, press the mic/mouse button for 5 seconds to turn the remote on. You can either use the remote as a mouse to control the cursor on the screen (old remotes) or use the voice command with the built-in microphone in the remote (new remotes).



14 Personalize your Ocea Pro

Your Ocea Pro is ready. Use the Touch screen or the Zapp remote to navigate the TV, install and manage apps, and personalize your Ocea Pro.